

elma tec clean A1

**LIQUID, MILDLY ALKALINE ULTRASONIC CLEANING CONCENTRATE
FOR GLASS AND CERAMIC SUBSTRATES, PCBs AND PLASTIC PARTS**

Description

Suitable for the fine cleaning of glass and ceramic substrates in optics and electronics: glasses, optical assemblies (incl. framing).

For the precision cleaning of electromechanical ensembles and PCB's, also for cleaning for inspectional purposes of PCB's.

Further on valid with good results for the cleaning and rebrighting of faded casings made from plastic materials and of faded lamella curtains.

The cleaner removes residues of light polishing suspensions, grease/oil, residues of activated fluxes (of RA-type), dust, fingerprints. Further on it removes residues from tea, coca cola, milk.

Application and dosage

Dosage: 3 - 10 %, temperature: 40 - 80°C (PCB's at ~ 65°C) duration: 3 - 10 min with ultrasonics.

Hotline for application consulting

Working days: Tel. ++49 (0) 7731 882-287. Email: chemlab@elma-germany.com

Safety recommendations

The concentrate is classified as Irritant (Xi, R41) according to the German regulations on dangerous substances / EC directives. Observe the hints indicated in the Safety Data Sheets. Always handle chemicals with care.

Physical-chemical characterisation

Density: 1.01g/ccm, pH (concentrate): 10.5 - 11.

Ingredients according to Annex VII, A, EC-Regulation 648/2004 (detergents): 5-15% anionic surfactants, <5% non-ionic surfactants, <5% NTA. Does not contain phosphates or silicates.

Disposal

The surfactants in our product meet the criteria for biodegradation as laid down in Annex III of the Regulation (EC) No 648/2004 on detergents.

The cleaning bath can be fed into the public sewage system after neutralisation; observe the local pH limit values and make sure that the contamination contained complies with the local sewage regulations.

For neutralisation we recommend: use acetic or citric acid in an ultrasonic bath – do not use hydrochloric or sulphuric acid.

European waste code: 20 01 29*, „detergents containing dangerous substances“.

Volumes, storage and transport

Available volumes: 2.5 litre, 10 litre and 25 litre can.

Shelf life: 5 years from date of production (see stamp on label) at a temperature between 5 and 30 °C.

Classification for all means of transport: no hazardous material.

Elma Hans Schmidbauer GmbH&Co KG

Kolpingstr. 1-7, D-78224 Singen

e-mail: info@elma-germany.com

17.08.05/ \\Elmakol141\D\Produktinfos\englisch\word\P_tec clean A1_GB.doc

Tel.: ++49 (0) 7731 882-0

Fax: ++49 (0) 7731 882-266

www.elma-germany.com