

PRESS RELEASE

Mass finishing of joint implants

The contact surfaces of hip and knee implants must be homogeneous, precise and very smooth. In order to achieve this, OTEC has developed special mass finishing processes for drag finishing (see fig. 1 drag finishing unit).



Fig. 1: Drag finishing unit (photo: OTEC)

In this process, the workpieces are clamped in specially designed holders and drawn through a series of grinding and polishing media in a number of processing stages. Clamping the workpieces eliminates any danger of damage caused by the workpieces colliding with each other. Especially when treating the complex surface geometry of a knee joint, it is important for the material to be removed evenly during grinding and polishing, in order to ensure a perfect fit. For this purpose, OTEC has carried out numerous trials and developed workpiece holders which guarantee precisely this.

As a rule, items such as knee joints are processed in two stages as follows:

1) Wet grinding

During wet grinding the knee joints are dragged through a special plastic abrasive media. A water/compound mixture is added to the **media** in a continuous flow process; this mixture carries away the material removed and is discharged into an external process water treatment system (such as a microfiltration unit). This flow

PRESS RELEASE

through process ensures that the workpiece remains clean at all times. The water/compound concentration can be preset by means of the Siemens S 7 control unit, considerably improving the consistency and reliability of the process.

By varying the depth to which the workpiece is immersed in the media and the speed of rotation, and thereby controlling the contact pressure of the abrasive on the workpiece, this process can achieve Ra values of up to 0.08 μm . The processing time for this is about 2 – 3 hours.

After wet grinding, the workpieces are in such a perfect condition that they can be polished immediately.

2) Dry polishing

During dry polishing, the knee joints are dragged through specially treated (impregnated) natural abrasive media such as walnut shell granulate. During impregnation, the granules receive a coating which basically consists of a special oil and aluminium oxide. The motion of the workpiece through the granulate and the resulting friction smoothes and polishes the workpiece. This process enables surfaces with Ra values of up to 0.01 μm to be achieved. This corresponds to the surface quality attained by manual polishing. The oil/aluminium oxide powder mixture has to be replenished at regular intervals in the form of a polishing cream in order to maintain a consistent polishing performance.

The processing time is normally 1 – 2 hours.



Fig. 2: Knee joint before (rear) and after (photo: OTEC)

The DF series of OTEC drag finishing machines can also be equipped to carry out both process stages automatically. This eliminates the time-consuming procedure of

PRESS RELEASE

removing and reclamping the workpieces. In the OTEC DF-10 Tools drag finishing machine, for example, 20 knee joints can be clamped at one time and processed in about 3 – 5 hours.

A further key advantage of the OTEC technology is a high degree of reliability. All relevant parameters can be set at the machine, documented and stored as programs. In order to obtain perfect results for any giving application, it is essential to choose right combination of all relevant process parameters. In order to determine the most suitable process, potential customers are invited to take advantage of the sample finishing service offered by OTEC's research lab. This service is available worldwide!

OTEC Präzisionsfinish GmbH

OTEC is a medium-sized manufacturer of drag-finishing and disc-finishing machines. Founded in 1996 by Helmut Gegenheimer, the company has successively established itself on the market through new machine concepts and numerous patented processes. Initially in the jewellery industry then increasingly in the tool manufacturing, pharmaceutical and automobile industries, as well as in the fields of medicine and CNC processing technology. The key to success has always been new, better solutions which are superior to the surface treatment processes previously used. Today OTEC is a technological leader in many markets and maintains a presence all over the world with branches of its own

Press contact

OTEC Präzisionsfinish GmbH
Dieselstrasse 8 - 12
75334 Straubenhardt-Feldrennach
Germany
Tel. + 49 (0) 70 82 - 49 11 20
Fax + 49 (0) 70 82 - 49 11 29
Email info@otec.de
www.otec.de